



- NOTES:
 1- ATTACH RECEPTACLE TO RECEPTACLE BOX THEN ATTACH TO FRONT COVER USING SCREWS PROVIDED.
 2- ATTACH FRONT COVER TO BASE (804435) USING 4- 85589 PAN HEAD SCREWS.
 3- PUT 4- 85132 HEX HEAD SCREWS INTO BAG AND SEAL.
 4- PLACE BASE ASSEMBLY BAG CONTAINING SCREWS AND 2- 804437 EXTENSIONS INTO BOX FOR SHIPPING.

ITEM NO.	PART NUMBER	QTY.
1	85589	6
2	85132	4
3	804666	1
4	804435	1
5	804437	2
6	RECEPTACLE	1
7	803639	1
8	85466	4
9	803562	8

REV	DATE	NOTES	BY	NAME	DATE
				DRAWN WWebber	22 Aug 2017
				CHECKED	
				ENG APPR	
				MFG APPR	
				Q.A.	
				MATERIAL	COMMENTS:
				FINISH	
				APPLICATION	DC NOT SCALE DRAWING

TITLE:
8" H SUB BASE ASSEMBLY

SIZE G	DWG. NO. 804667	REV 00
SCALE: 1:8	WEIGHT:	SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.